



PACKAGING



PRIMEDAMP

Multipurpose, water based, epoxy moisture barrier


MIXING



Description

A multipurpose, water based, three-pack epoxy resin. **PrimeDamp** has excellent adhesion to most correctly prepared building surfaces such as brick, block, concrete and masonry.

APPLICATION



Uses

A damp proofing membrane on concrete floors prior to floor coverings where moisture exceeds Australian Standards and to stop dampness in floors and walls of cellars, basement, etc. A primer for damp/immersed applications, smooth concrete and tiles.

PrimeDamp has a water vapour transmission (WVT) rate of 14g/m²/24 hours when properly applied and cured. All subsequent floor coverings or paint must have a higher WVT than **PrimeDamp** to ensure no vapour condensation build-up.

Coverage

3kg kit

Use	No. of coats	Coverage
Dampproofing	2	9m ²
Primer	1	18m ²

Specification

The epoxy resin shall be water based and when used for damp proofing shall have a WVT rate of 14g/m²/24 hours such as **PrimeDamp** manufactured by Construction Chemicals and be applied in accordance with the manufacturer's instructions.

Surface Preparation

The surface must be structurally sound and clean, free from laitance, dust, waxes, paint and other contaminants. Apply **PrimeDamp** to wood floated or broom finish concrete. Steel floated and contaminated surfaces must be suitably abraded with dustless shot blasting or grinding then washed thoroughly and surface water allowed to dry. Porous surfaces must be dampened prior to **PrimeDamp** application.

Mixing

1. Stir part A and B separately.
2. Mix parts A and B together in a clean mixing container, with a low speed electric drill and a mixing paddle for at least 3 minutes until the colour is uniformly form.
3. Then add in the part C powder, mix until uniform consistency appearance is achieved.

Application

Apply with a brush or broom (for superior adhesion and improve penetration into the substrate), or a roller. On porous concrete prior to applying **PrimeDamp**, dampen floor with water and avoid puddles. Apply the mixture in two thin coats, in different directions to avoid pin holes. Allow 24 hours before continuing work.

Recoat Time

2 hours at 25°C. Apply adhesives or toppings between 24 and 48 hours after second coat.


Pot Life

50 minutes @ 25°C @ 50% relative humidity.

Full Cure

7 days @ 25°C @ 50% relative humidity.

USES



SUBSTRATE

Concrete
Brick, Block
Cement render
Stone Walls



UNITY
BUILDING MATERIALS
VALUE CREATION

www.unitymarketing.com.my

The information contained in this technical publication is based on our current knowledge and experience and is provided as a guide only. In view of the many factors that may affect application it is the user's sole responsibility to ensure suitability for a specific purpose.